

CAPTURE MANAGER Software installation

Before installing a new version of Capture Manager, all previously installed versions should be uninstalled.

 **Warning** back up any previously installed Capture Manager Databases before starting the install process, using the backup function.

1. Plug the USB Flash Drive in to the PC's USB port
2. Windows Auto Play should appear. If this does not happen please proceed to Window version specific installation
3. Select "Open the folder to view the files"
4. Select the Capture Manager folder and double click on "**Setup.exe**"
5. The Capture Manager setup wizard should appear and guide you through the install process. If this window does not appear, then please follow the steps below

Windows XP

1. Click 
2. Click 
3. Type **D:START.EXE**, where D is the drive letter of your CD-ROM drive
4. Click 
5. The Capture Manager setup wizard should appear and guide you through the install process

Windows Vista/7

1. Click 
2. Locate and start the  **Run** command in the "Accessories" folder in "All Programs"
3. Type **D:START.EXE**, where D is the drive letter of your CD-ROM drive.
4. Click 
5. The Capture Manager setup wizard should appear and guide you through the install process.

The Capture Manager Instruction Manual is located in the Capture Manager folder on the USB Flash Drive (memory stick).

www.torqueleader.com

CAPTURE

Manager



Order Code	Model
036700	Capture Display
036710	Capture Manager - PC Software
036805	CS 2 Capture Sensor
036810	CS 10 Capture Sensor
036820	CS 50 Capture Sensor
036830	CS 250 Capture Sensor
036845	CS 1500 Capture Sensor
036226	Capture Cable - Capture Display to Custom Sensor
036246	Capture Cable - Capture Display to Capture Sensor
036251	Capture Cable - Capture Display to SDX Screwdriver
036256	Capture Cable - Capture Display to ETX Wrench
036771	Capture Sensor ISO 1500/90° Adaptor
D18205	Capture Sensor ISO-A Mount
036772	Capture Sensor Quick Change Plate



Capture Display



CS 1500 Sensor

Torqueleader Sales Hotline **+44 (0) 1483 894 476**
or visit **www.torqueleader.com**